



FTGM / TGM Ground Mount Delineator Post

Installation Instructions

1) Preparation

Assemble the materials and tools needed.

2) Installation

- a) Manually dig a pilot hole 18 inches deep into the ground.
Alternative methods include using a post hole digger or an auger.

- b) Place the post with anchor attached into the pilot hole to the proper depth on the post to the first ring on hinge.

- c) Back fill around post and tamper in firmly.

Important Notice to Purchaser

The following is made in lieu of all warranties, expressed or implied, including the implied warranties of merchantability and fitness for purpose: Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith. Neither manufacturer nor seller shall be liable either in tort or in contract for any loss or damage, direct, incidental, or consequential, arising out of the use of or the inability to use the product.