



TSM / FTSM Surface Mount Channelizer Post Installation Instructions

A) Preparation

- 1) Assemble the materials and tools needed.

B) Installation

- 1) Insert top section of post into the base.
- 2) Align pin hole with the base.
- 3) Insert locking pin to secure post to base.
- 4) Bases can be affixed to the pavement using butyl rubber pads, anchor bolts or 2- part road marker epoxy.

C) Removal

- 1) To remove the post, use drift pin to remove locking pin, lift post from base.

D) Important Notice To Purchaser

The following is made in lieu of all warranties, expressed or implied, including the implied warranties of merchantability and fitness for purpose: Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith. Neither manufacturer nor seller shall be liable either in tort or in contract for any loss or damage, direct, incidental, or consequential, arising out of the use of or the inability to use the product.