

Snow Poles & Posts Installation Instructions

A) With Metal Delineator Posts

- 1) Slide snow pole down into "U" channel of post a minimum of 12 inches, or all the way to the ground.
- 2) Secure pole to post with wire, 2 screws or 2 nails.
- 3) Pole should extend 6 feet above delineator post.

B) With Flexible Delineator Posts

- 1) Work bottom end into ground at base of flexible post.
- 2) Secure pole to post with nylon ties in two places.
- 3) Pole should extend 6 feet above delineator post.

C) On Wooden Guardrail Posts

- 1) Install 12-inch section of 1 1/2" perf. square steel tube on block cut or guardrail post.
- 2) Slide snow pole down through steel tube so that bottom end extends is flush with bottom of tube.
- 3) Tighten bolts or securely into post or block cut.
- 4) Pole should extend a minimum of 6 feet above guardrail.

D) To Fire Hydrants & Power Boxes

- 1) Drill 2 holes through snow pole approximately 1/2 way up the height of the hydrant or power box.
- 2) Place pole such that at least 2 feet of the pole is against the hydrant or box.
- 3) Secure pole with 36-inch nylon ties, 2 holes drilled through snow pole.
- 4) Pole should extend 6 feet above hydrant or box.

E) Installation Into Ground

- 1) Create a hole in ground 12 inches deep and 2 inches wide.
- 2) Place a 12-inch length of 1-1/2" PVC pipe into ground so that top of pipe barely extends above ground surface.
- 3) Back fill against PVC pipe and compact soil.
- 4) Slide snow pole into pipe.
- 5) Snow pole should extend no more than 6 feet above ground.

F) Important Notice To Purchaser

The following is made in lieu of all warranties, expressed or implied, including the implied warranties of merchantability and fitness for purpose: Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith. Neither manufacturer nor seller shall be liable either in tort or in contract for any loss or damage, direct, incidental, or consequential, arising out of the use of or the inability to use the product.