Bottom Lock Installation Procedures

One of the biggest advantages of Pexco PDS® Bottom Lock slats is their easy installation. Pexco is the largest manufacturer of Bottom Locking Slats and has more than 50 years of experience producing this product, supported by an exclusive proprietary locking design.
The slats feature a bottom locking system that creates a simple "snap-in" effect. This provides a secure hold, improves stability, and helps deter vandalism.

The installation process is simple:

Step 1: Insert the bottom rail horizontally into the first full diamond at the bottom of the fence, with the open side facing up.
Step 2: Insert vertical slats with the beveled/notched end downward so the slat engages and interlocks with the bottom rail.
Step 3: Push the vertical slat into the horizontal channel to lock it in place.

This efficient installation method makes Bottom Lock slats a practical choice for both large-scale and smaller improvement projects.

Interested in learning more or speaking with an expert?
Contact us for more information at: **https://www.pexco.com/contact-us/**

Tacoma, WA 98424 // **Athol, MA 01331**
PHONE 800.755.SLAT (7528) / EMAIL fence.sales@pexco.com
PEXCO.COM